DIGITAL MOISTURE METEROPERATION MANUAL


Thank you for purchase our Products. Please read this manual before it. It will tell you how to use it and simply inspect it use so exert ruggedization and durable of it's The as to the merit. instrument is a delicate one, which used to measure the containing water of wood, bamboo, paper etc.

FEATURES:

- * Digital large size LCD display
- * Range: 5% to 40%
- * Resolution:1%
- * High resolution and response quickly
- * Date hold
- * Symbol and unit display can read the value conveniencely
- * Low battery symbol "
- * Power: one 9V battery
- * Dimension: 129×63×32mm
- * Weigh: approx. 116g (including battery)
- * Operation temperature: 0 C to 40 C (32 F to 104 F) 0 to 70%RH

FRONT PANEL DESCRIPTIONS

- 1. Probe shield
- 2. Measure probe
- 3. Date-hold button
- 4. Power button
- 5. LCD display
- 6. Battery cover



MEASURING METHOD

- A. Press power button to pen the meter, and then insert the pins into the object approx. 5mm, it will display the containing water of the object on LCD.
- B. Press "HOLD" button then can hold current value with " H symbol, press "HOLD" again, which can cancel hold function.
- C. After measuring, press "POWER" button, turn of power and cover probe shield, then measuring is over.

NOTES

- 1. The pins are very sharp and don't let children play.
- 2. Don't point pins at humans or animal to avoid the injury others

when using it.

3. The high resistance and well insulator. Keep instrument dry and clean insure the accuracy of measure when store and using it. as to 4. As the battery power is not sufficient. LCD will display

and replacement of one new battery type 9V is required.

- 5. Removed the battery if don't use it for a long time.
- 6. It has a large impact on wood moisture in some conditions, such as Special wood, different temperature, the wood growing up in deferent place. The simple moisture meter is just based on one kind of wood, and it has not the correction function on Special wood, different temperature, the wood growing up in deferent place. different will have the different measuring So the meter value.