

绘多彩2010年EPSON/CANON/HP/BROTHER连供价格

序号	型号	颜色	墨盒型号	适用机型	
1	NX100	4色	T0881-0884/T0691-0694 (9个触点)	NX100	
2	NX200			NX200	
3	NX410			NX410	
4	S20		T0711-T0714 (9个触点)	S20	
5	SX200			SX200	
6	SX400			SX400	
7	T26, TX106, TX109		T0891-T0894 (9个触点)	T26, TX106, TX109	
8	ME30		T1091-T1094 (9个触点)	ME30	
9	ME300			ME300	
10	TX100, TX200, TX400		T0731N-T0734N (9个触点)	TX100, TX200, TX400	
11	T10, T11, T20			T10, T20	
12	C79		T0731-T0734 (9个触点)	C79, C90, C92	
13	CX3900			CX9300, CX9305	
14	CX4900			CX4900, CX4905, CX5900, CX5905, CX6900F, CX7300, CX8300, CX9300	
15	CX5500		CX5600, CX5500, CX5501, CX5510		
16	ME70	5色	T1091, T1091-T1094 (9个触点)	ME70	
17	T30, T33		T1051, T1051, T0732-T0734 (9个触点)	T30, T33	
18	D120		T0711, T0711-T0714 (9个触点)	D120	
19	C120		T0681, T0692-T0695 (9个触点)	C120	
20	C110		T0731, T0731-T0734 (9个触点)	C110	
21	Artisan 800	0	T0981N-TT0986N (9个触点)	Artisan 800	
22	Artisan 700			Artisan 700	
23	Artisan 50			Artisan 50	
24	T50		T0821N-T0826N (9个触点)	T50	
25	T60		T0851N-T0856N (9个触点)	T60	
26	PX700, PX800, P50		T0801N-T0806N (9个触点)	PX700, PX800, P50	
27	R265, R285		T0801-T0806 (9个触点)	R265, R285	
28	R260, R280			R260, R280	
29	R290, R270		T0821-T0826 (9个触点)	R270, R390, RX610, RX690, R290	
30	R230		T0491-T0496 (7个触点)	R210, R230, R310, R350, RX510, RX630	
31	1390	T0851-T0856 (9个触点)	1390		
32	R1900	8色	T0870-T0874 T0877-T0879 (9个触点)	R1900	
33	ME1+	4色	T056-T058	ME1, ME1+, ME100, CX1500	
34	ME2		T0761-T0764	ME2	
35	ME200		ME200		
36	PHOTO 20		T0841-T0844	PHOTO 20	
37	C65		T0461, T0472-T0474	C63, C65, C83	
38	C67		T0631-T0634	C67, C87	
39	C80		T0321-T0324	C70, C80, CJ100	
40	C82		T0321, T0422-T0424	C82	
41	R250		T0561-T0564	R250	
42	CX3500		T06461, T0472-T0474	CX3500, CX4500	
43	CX3700	T0631-T0634	CX3700, CX4700, CX4100		
44	CX5100	T0321, T0422-T0424	CX5100, CX5200, CX5300, CX5400		
45	RX430	T0561-T0564	RX430		
46	830	6色	T026-T027	810, 820, 830, 830U	
47	EX3		无芯片	EX2, EX3, 1200	
48	1290		T007-T009	1290	
49	950	7色	T0331-T0336 (2个黑色墨盒)	950	
50	2100		T0341-T0348	21, 002, 200	
51	R800	8色	T0540-T0544, T0547-T0549	R800, R1800	
52	R1900		T0870-T0874, T0877-T0879	R1900	

53		R2400		T0591-T0599	R2400	
54	CANON	IP3680	5色	821BK, 821M, 821Y, 820PGBK, 821C	IP3680, IP3600	
55		IP4680			IP4680, IP4600	
56		MP628			MP628, MP620	
57		MP628			MP638, MP630	
58		IP3300	4色	5BK, 8C, 8M, 8Y	IP3300, MP520	
59		IX4000			IX4000, IX5000	
60		IP4300	5色	8BK, 5BK, 8C, 8M, 8Y	IP4200, IP4300, IP5300, IP5200	
61		I6100	4色	3EBK, 6C, 6M, 6Y	I6100, 6500, S6300	
62		IP3000			IP3000, I560, 550I, 850I, S500, S530, S700	
63		IP1000	5色	24BK, 24C	IP1500, IP1000, I255, IP2000, I455, 450I, S300, S330	
64		MP530			MP530, MP500, MP510	
65		IP4000	6色	6BK, 6C, 6M, 6Y, 6PC, 6PM	IP4000, IP5000, 860I, I865	
66		IP6000D			IP6000D, 905D, I900D	
67		S900			S900, F930, F890, 895PD	
68	F9000	F9000, 9100I				
69	I990	I990				
70	IP8500	IP8500				
71	I9950	8色	6BK, 6C, 6M, 6Y, 6PC, 6PM, 6R, 6G	I9950		
72	PR09000			PR09000		
73	HP	88	4色	HP88 (69 or 28ml) C9385AN HP88 (28ml) C9386AN/87AN/88AN	HP Officejet Pro K550/K550dtn/K550dtwn/k5300/k7380/k5400	
74		8		HP10 (69 or 28ml), C4844A HP11 (28ml), C4836A/37A/38A	HP Designjet 100/100 plus; Business inkjet 1100 series/1300/2300; Deskjet 2000 series; Office jet 9110 /9120/9130	
75		564		HP564/HP364	HP6380/ D5460	
76		10V11	HP11 (28ml) C4836A/37A HP82 (69ml) C4913A HP84 (69ml) C5016A/17A/18A	HP Designjet 10ps, 20ps, 50ps; HP Designjet 120series;		
77		564	5色	HP564/HP364	HP6380/ D5460	
78		801	6色	HP02/ 363/ HP801/ HP177	HP3110/3310/8230/8250/C5180/C6180/ C7180/D7160/D7360/8238/3308/3108/3210	
79	Brother	950	4色	LC950BK/C/M/Y LC900BK/C/M/Y LC41BK/C/M/Y LC47BK/C/M/Y	MFC-640CW/FAX-1840C/MFC-425N/MFC-3240C/ MFC-215C/MFC-5440N etc	
80		960		LC960BK/C/M/Y LC51BK/C/M/Y LC57BK/C/M/Y LC1000BK/C/M/Y	MFC-440CN/MFC-240C/DCP-540CN/DCP-130C/ DCP-330C etc	
81		980		LC38/L61/LC65/LC67/LC970L/LC980/ LC1100/LC16	Brother DCP-165C/DCP-145C/MFC250C/ MFC290C/MFC-490CW/MFC-5490CN/ MFC-5890CN/MFC-6490CW etc	