ZC106

Conventional Manual Call Point

SPECIFICATIONS

Operating Voltage Range: 24 VDC Volts

10 to 30 mA @ 24 VDC Alarm Current

Operating Humidity Range: 10% to 93% Relative Humidity, Non-condensing

Operating Temperature Range: -10°C to 50°C (14°F to 122°F)

Input terminal Wire Gauge: 12 to 18 AWG

Length 88mm, Width 88mm, Depth 50mm Dimensions: Weight: Net Weight 172g, Gross Weight 185g

codes, ordinances, and regulations.

BEFORE INSTALLING

NOTICE: This manual should be left with the owner/user of this equipment.

GENERAL DESCRIPTION

The ZC106 conventional manual call point designed for in the front of the product housing. conventional fire alarm system for reporting fire or

emergency condition by pressing its breakable glass. The igure 1. Install and Wiring diagram:

manual call point can be test by a test key without

breaking the glass.

Loop Design and Wiring

The fire alarm control panel Zone wire can be connected to terminal 2(+),4(-).

And there is a 5.1V Zener diode should be connected to terminal 1A and 4A.(included by default).

If the manual call point is in the end of the zone wire, a 5.6K resistance should be connected to terminal 2, 4.

INSTALLATION

NOTE: All wiring must conform to applicable local

Mounting Indoor Wall

- 1. Attach mounting base to wall at 1.5 mesterigh.
- 2. Connect field wiring to terminals
- 3. To attach product to mounting base.
- 4. Secure product by tightening the one mounting screws

ZONE+ ZONE -

Please refer to insert for the Limitations of Fire Alarm Systems

THREE-YEAR LIMITED WARRANTY

Convoy Security warrants its enclosed smoke detector to be free from defects in materials and workmanship under normal use and service for a period of three ye from date of manufacture. Convoy Security makes no other express warranty for this smoke detector. No agent, representative, dealer, or employee of the Company the authority to increase or alter the obligations or limitations of this Warranty. The Compalingation of this Warranty shall be limited to the repair or replacement of any part of the smoke detector which is found to be defective in materials or workmanship under normal use and service during the three year period commencing w the date of manufacture. After phoning Convoy Securitychnical support number for a Return Authorization number, send defective units postage prepaid to Convoy Security local representative office. Please include a note describing the malfunction and suspected cause of failure. The Company shall not be obligated to repair replace units which are found to be defective because of damage, unreasonable use, modifications, or alterations occurring after the date of manufacture. In no case the Company be liable for any consequential or incidental damages for breach of this or any other Warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other Warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other warranty, expressed or implied whatsoever, even if the loss or damages for breach of this or any other warranty. is caused by the Compasynegligence or fault. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.